



The only tricky part to this part is boring the 1.124 X .312 DP bore to the right size. This bore is for a light press fit of a bearing. Other than that everything else is pretty standard machining. Just watch that you get the bearing bore and the .625 X .190 deep C-bores on opposite sides of the part from each other.