



Nothing fancy here, just a piece of aluminum with 4 holes drilled in it. You need one of these to go with each linear bearing. That would be 6 for a Alfamill and 8 for a CNC router.